

Content

1		tenttent	
2	Area	of Application	. 1
3	Resp	oonsible Persons	. 1
4	Cond	duct in case of technical faults	2
5		ness and cleanliness	
6	Acce	ess Permission	2
7	Oper	rating hours	2
8	First	Aid	3
	8.1	First aid equipment	3
	8.2	First responders	3
	8.3	Emergency/conduct in case of accident	3
	8.4	Emergency shower	3
	8.5	Eye shower	3
9	Fire	protection	4
	9.1	Emergency/conduct in case of fire	4
	9.2	Fire protection equipment	4
	9.3	Fire protection measures	4
10) Gene	eral security regulations	5
	10.1	Clothing/protective gear	5
	10.2	Eating, drinking, smoking	5
	10.3	Youths, pregnancy	5
	10.4	Working alone	5
	10.5	Experimental Setups	5
	10.5.		
	10.5.	.2 Protection against electrical hazards	7
	10.5.		
	10.5.		
	10.5.	.5 Protection against X-rays and laser beams	7
		Handling of machines / devices	
	10.6.		7
	10.6.		
	10.6.		
	10.6.		
	10.6.		
	10.6.		
	10.7	Dealing with hazardous substances	
	10.7.		
	10.7.		
	10.7.		
	10.7.		
	10.7.	, , ,	
		Dangerous activities	
	10.9	Unsupervised experimental setups	9

2 Area of Application

These laboratory regulations are valid for working in the Laboratory of Nano-Optics, in the department of Physics, Faculty IV at the University of Siegen.

3 Responsible Persons

Professor Mario Agio is the responsible supervisor of the Laboratory of Nano-Optics. His responsibilities include ensuring the entrepreneurial duties and working conditions act (Arbeitsschutzgesetz) and ordinance on hazardous substances (Gefahrstoffverordnung). The following named persons are contact persons for the laboratory:



Name	Function
Assegid Flatae	Yearly instruction of employees and students working in the lab.
Sharon Harvey	Purchase and hand out of personal safety equipment together with the researchers.
Assegid Flatae	Preparation of operating instructions for hazardous substances or machines.
Assegid Flatae/ Mario Agio	Evaluation of the chemistry lab risk assessment and approval.
Jan Krause	Arranging the necessary regular checks of machines, sockets and laboratory-waste removal protocols.
Jan Krause	Initiation/execution of the test of portable electrical equipment and gas sources.
Jan Krause	Monthly check of emergency and eye showers and refilling any used first aid-equipment in the chemistry laboratory

4 Conduct in case of technical faults

- In the event of any malfunction of machinery, the responsible persons must be contacted immediately.
- Disruptions to the technical infrastructure (gas, water, electricity, sewage, ventilation, etc.) must be reported to the central control center (ZLT) of the university (Tel -4321) without delay.

5 Tidiness and cleanliness

- Order and cleanliness are important foundations of occupational safety.
- All used materials should be cleaned after use and cleared in the appropriate cabinets etc.
- Equipment that is no longer required must be dismantled; temporarily unused equipment must be placed in a condition that excludes hazards (e.g. ventilation of glass vacuum vessels).
- It is best to avoid placing materials on the floor throughout the laboratory so that there are no tripping hazards. Connecting cables (electricity, water, gas, telephone, test leads) should be routed above the traffic areas (at a minimum height of 2 m). If this is not possible, they must be covered with cable bridges.
- Spilled liquids must be absorbed immediately.
- The storage of required materials at the workplace must be carried out in such a way that there are no increased hazards (especially risks of cuts and stabs).
- Especially above 1.4 m height, all materials should be stored in such a way that they do not fall accidentally but can be removed safely.
- At the end of work, the used equipment (if possible) should be switched off, cleaned and stowed so that the cleaning staff can safely clean the laboratory. If this cannot be guaranteed, a message to Department 5.4 (Tel. 3280) is required so that the room is taken off the cleaning list.

6 Access Permission

- Access to the laboratories is only permitted with the express permission of the responsible persons.
- Persons who are not affiliated with the laboratory may only be present in a laboratory with the permission of the person responsible for the laboratory in question or in the company of a laboratory worker.
- Unauthorized persons are to be expelled from the laboratory rooms.

7 Operating hours

Operation in the laboratory is only permitted at the following times:

- Monday to Saturday from 07:00 until 22:00
- Working on Sunday and public holidays is prohibited!

For activities outside of these times, the expressed consent of the responsible persons is required. For these times, make sure that:

- First responders are available at all times
- Personnel is available, who could instruct the rescue service.

UNIVERSITÄT SIEGEN

Regulations for Chemistry Laboratory

8 First Aid

8.1 First aid equipment

The locations of the nearest first aid kits as well as the nearest emergency terminal are noted on the emergency notice on the laboratory doors.

8.2 First responders

There is a list of the closest first responders on the emergency call sign on the laboratory doors.

8.3 Emergency/conduct in case of accident

In case of emergencies / accidents, the following procedure should be followed:

- 1. Ensure self-protection!
- 2. Secure the danger area or take people out of danger area.
- 3. Consult first responder / paramedic, if necessary place emergency call.

Emergeny call: to the university's central control centre, emergency no. (0271 / 740) 2111.

who will redirect the emergency call to the rescue service and organizes further measures, such as

- Informing the Rescue Assistant of the University
- Opening of the entrance gates for the rescue service,
- Informing the caretaker who will instruct the rescue services,
- Notify more First-responders.

Outside the duty of the ZLT (Mon-Fri 06:00-22.00, Sat. 08-12:00) this emergency number is forwarded to the security service, which then causes the alarm of the external rescue workers. The briefing of the rescue service as well as the alerting of first aiders must be organized in this time!

If the number cannot be reached, the fire-brigade and rescue control center be contacted directly from all internal telephones at 6-112.

- **4.** Provide first aid, care for injured persons.
- 5. Alert and guide Emergency Service (if necessary via caretaker/porter).
- **6.** In the event of accidents involving hazardous substances, information on the hazardous substance (e.g. safety data sheet) must be given to the rescue service.
- 7. Inform your supervisor.
- 8. All injuries (incl. minor injuries) must be documented in the first aid book!
- **9.** If it is necessary to consult a doctor or in case of absence from work for more than 3 days, the responsible person for Laboratories must prepare an accident report. This report will be sent first to department 1.1 and then on to Unfallkasse NRW.
- **10**. Refill any used first aid-equipment. All refill materials can be obtained at department 1.1 (Tel. -3311 or 5771)

8.4 Emergency shower

- The emergency showers are located above the laboratory door.
- The emergency showers are used for the first "rough decontamination" (maximum 3 minutes) in case of
 extensive contact with hazardous substances. They can also be used to extinguish a person who is on
 fire.
- Longer periods of use should be avoided as the injured person may suffer hypothermia; also water damage could be caused.
- Further decontamination / rinsing takes place at the hospital.
- The emergency showers have to be checked monthly (responsible person: see section. 3).

8.5 Eye shower

- The eye showers are located at the sink.
- After exposure to hazardous substances, rinse eyes under running water for at least 10 minutes. The eyelids are to be kept open, contact lenses are to be removed as far as this is possible.
- If there is no eye wash available, an eye can also be rinsed under a normal tap. The head should be held in such a way that the water does not flow towards the second eye.
- The eye showers have to be checked monthly (responsible person: see section 3).



9 Fire protection

More details concerning fire protection can be found in part A and B of fire protection regulations (Brandschutzordnung) of the University of Siegen.

9.1 Emergency/conduct in case of fire

Always:

- Ensure self-protection!
- EMERGENCY CALL -2111 (ZLT) or press emergency button (on the corridor).
- If possible switch off experimental set-ups and energy sources (emergency stop, fuse).
- In case of incipient fires try to put out the fire with suitable extinguishing agents.
- Keep distance to electrical equipment / voltage sources!
- In case of larger fires please exit the area quickly but calmly whilst
 - o closing doors and windows, but not locking these (Fire service would need to break them open)
 - o warning others and helping them to exit,
 - not using lifts
 - exit building by following the indicated escape routes to the meeting area (In front of building C).
- At the meeting point count and check if all persons belonging to working group (including students) are present.

9.2 Fire protection equipment

- The building is equipped with an automatic fire alarm system for the early detection of fires and the rapid alerting of affected persons.
- If the bell / horn / siren sounds, the building must be left immediately via the signposted escape routes to the meeting point.
- Fire extinguishers are in the corridors.

9.3 Fire protection measures

- All persons in the laboratory must be familiar with the locations of emergency stop facilities (electricity / gas), escape routes, first aid facilities (first aid kit, emergency shower, eye shower) and fire extinguishing equipment.
- Always keep escape routes clear to full extent (doors + windows!)
- Easily combustible materials (paper, wood, etc.) must not be placed in escape routes.
- Storage rooms for wood, paper, flammable liquids or gases or other easily flammable substances must not be entered with an open flame. Smoking bans must be followed.
- Flammable liquids may only be kept in the workplace up to the amount of daily requirement. The provision of combustible packaging material should not exceed the need for one working day.
- Remove waste and shavings regularly.
- Used, oily cleaning cloths must be collected in the designated, closed refractory containers due to their risk of auto-ignition.
- At the end of working time make sure that lights and all electrical appliances are switched off. Excluded
 are devices that are in continuous operation.
 Safety, telecommunication and fire alarm systems remain permanently operational and must not be
 switched off. Close all the windows and doors.
- Burning candles (for example on Advent wreaths or arrangements) are prohibited in all offices and service areas.
- Welding, cutting, soldering and cutting work requires special safety measures and (except in the
 designated workshops) written permission (welding permit). The permit must be obtained from the responsible site supervisor or the responsible departmental head of the building department.
- The installation and use of other than official electrical equipment is prohibited without special permission.
- Defects in fire protection equipment and damage to electrical installations as well as signs (flickering light, stench, etc.) must be reported immediately to the fire prevention officer or supervisor.
- Blown fuses, defective sockets and cables must only be repaired by authorized specialists (Department 5.2).



- In the event of fires on electrical systems, the power must be switched off immediately by means of an emergency stop switch, provided that emergency stop switches are available in the premises.
- Smoke and fire doors are always kept closed unless they are equipped with self-closing devices. Laboratory doors should always be kept closed to prevent the dangerous spread of smoke in case of

The use of wooden wedges or other objects to keep doors open is prohibited.

10 General security regulations

10.1 Clothing/protective gear

- When working in laboratories, always wear the following work clothing / protective equipment:
 - Chemical safety goggles
 - Lab coat with long sleeves
 - Long pants or long skirt, if possible made of cotton
 - Firm, closed footwear (no sandals, slippers, etc.).

The clothing must cover all skin areas below the neck (except hands)!

- Do not use jewellery (rings, necklaces) and cosmetics for hygienic reasons.
- The required protective equipment is available at: Assegid Flatae
- As a general rule: Protective equipment must be visually inspected before use. Damaged protective equipment may not be used further!
- When transferring hazardous substances, suitable protective gloves must be worn. Caution: Hazardous protective gloves only provide protection against individual substance classes, so the appropriate gloves (see Hazardous Material Operating Instructions) must be selected according to the activity.
- Disposable gloves made of for instance nitrile, vinyl, latex or similar do not provide effective protection against hazardous substances, especially not for prolonged contact. For reasons of hygiene, however, they can be worn under suitable protective gloves.

10.2 Eating, drinking, smoking

- Food may not be eaten or stored in the laboratory rooms.
- Glasses, cups, etc. are forbidden in the laboratory because there is a risk of hazardous substances accumulating on these and absorption into the body when drinking.
- Smoking is as in all rooms of the university prohibited.
- Food may not be stored in the same refrigerators where hazardous substances are stored.

10.3 Youths, pregnancy

- Special restrictions apply to women, pregnant women and adolescents in accordance with the Maternity Protection Act, the Hazardous Substance Ordinance and the Youth Employment Protection Act.
- A pregnancy should be reported to the supervisor as early as possible so that appropriate protective measures can be taken.
- Pregnant women are expected to report the pregnancy early to Department 4 or Student secretariat so that the risk assessment for her can be updated together with Department 1.1 "Occupational Health and Safety".

10.4 Working alone

Working alone in the laboratories is prohibited. There must be at least one other person available, who can provide help in case of danger.

10.5 Experimental Setups

10.5.1 General

- Experimental Setups must be sufficiently steadfast, stable and suitable for the applied temperatures, chemicals and mechanical movements.
- In case of unattended endurance tests, protective measures for incidents (power failure, cooling failure, unexpected reactions) should be provided.
- After the end of the experiment, make sure that all gas and water connections are closed and the power supply is switched off.
- All experimental setups are to be designed in such a way that they can be easily put into a safe state in the event of danger by emergency stop switches (or similar devices)
- Test setups may only be put into operation for the first time if they have been checked by a responsible

Seite 5 von 9

Aktualisiert: 03.04.2025 Druck: 03.04.2025 Ersteller/Bearbeiter: Laboratory of Nano-Optics

person (see above).

Aktualisiert: 03.04.2025 Druck: 03.04.2025 Ersteller/Bearbeiter: Laboratory of Nano-Optics 2025_ENGL_Laborordnung_chemielab

UNIVERSITÄT SIEGEN

Regulations for Chemistry Laboratory

10.5.2 Protection against electrical hazards

- In setups containing electrical equipment, it must be ensured that they are undamaged and suitable for the purpose of the experiment.
- In areas where there is a possibility of liquid splash, only splash proof (water protected) equipment may be used (for example, next to sinks).
- Experimental setups must never be put into operation in which contact parts with dangerous voltages (such as main voltage) are freely accessible.
- Repairs and maintenance work on electrical equipment may only be carried out by suitably qualified persons (electricians).

10.5.3 Protection against mechanical hazards

- If there is a risk of parts that could spin out of the experimental setup, solid protective covers must be installed.
- With motions that occur at a speed of more than 10 mm / s, protective measures must be taken to prevent persons from reaching into the crushing zone or shear point. This can be prevented by means of fixed covers directly at the danger spots or an effective shut-off of the entire danger area.
- Take special care in the area of rotating rollers, shafts or gear parts. Due to entanglement hazard, these are to be secured in any case.
- Before carrying out any work on the set-ups, the relevant driver must be stopped and secured against being switched on again.
- Work on hydraulically or pneumatically operated parts of setups may only be carried out if they have been depressurized and secured against renewed pressure build-up. If movements are triggered by the pressure drop, these must be prevented by suitable measures, e.g. by fixing parts or approaching a previous secure position.
- Collect spilled hydraulic oil with a suitable binder (location: mechanical workshop) or cloth and dispose of it for disposal. Hot hydraulic oil can cause burns.
- When working in the vicinity of free-swinging parts such as pendulums or the like, secure them beforehand against movement or take them down.

10.5.4 Protection against thermal hazards

- When working with stoves, hot work pieces or open flames, make sure that there are no flammable
 materials (especially paper and hazardous substances) in the immediate vicinity. The surfaces of the
 work tables should not be flammable or covered with tiles etc.
- The work clothes should have the highest possible cotton content (artificial fibers ignite easily and stick to the skin).
- When handling hot parts, use tools (pliers, etc.) and wear heat-resistant protective gloves.

10.5.5 Protection against X-rays and laser beams

 When handling X-ray or laser radiation, the relevant safety regulations and operating instructions must be followed.

10.6 Handling of machines / devices

10.6.1 Instruction

- Machines and devices may only be put into operation by persons who have been instructed by one of the above responsible persons in the correct and safe handling.
- Instruction must be repeated annually. The instruction has to be documented by signature.
- Handling of machines and devices are to be carried out as work-related and due to their necessity.

10.6.2 Operational instructions for machines

For the handling of dangerous machines and equipment rules of conduct have been prepared by the responsible persons. These operating instructions list the most important protective measures and rules of conduct. These operating instructions must be observed!

10.6.3 Protective devices

- Machines may only be put into operation if the protective devices provided are in place and effective.
- The manipulation of protective devices is prohibited and may result in criminal prosecution!

10.6.4 Fume hoods

• The flaps at the front of the fume hoods should be kept closed as much possible.

Aktualisiert: 03.04.2025 Druck: 03.04.2025 Ersteller/Bearbeiter: Laboratory of Nano-Optics Seite 7 von 9 2025 ENGL Laborordnung chemielab



- Check the functionality of the hoods during each operation.
- Defective hoods must not be used.
- Experiments with larger thermal loads or exhaust operations must only be carried out in specially qualified and labelled fume hoods.

10.6.5 Cooling water

- Cooling water pipes for non-fixed equipment may only be laid as pressure-hose. The hose connections
 must be secured with clamps.
- With unsupervised experiments measures must be taken to establish a safe condition in the event of failure of the cooling water supply.

10.6.6 Working with vacuum equipment

Larger glass vacuum equipment must be fitted with a closed trigger or with a splinter guard (for
example, a tight-meshed wire net cover, protective screen in front of the equipment). For all work with
glass vacuum equipment, at least safety goggles with side protection must be worn.

10.7 Dealing with hazardous substances

10.7.1 General

- Prior to handling hazardous substances and before carrying out procedures in which hazardous substances may be released, the hazard potential must be determined and the necessary protective measures must be taken. In particular, the information from the following sources should be taken into account:
 - o Safety Data Sheets
 - Manufacturer or dealer catalogs
 - Literature or work instructions
 - Annexes to the Hazardous Substances Ordinance
- The identified special hazards (H statements) and safety advice (P statements) are binding parts of these laboratory regulations.
- Handling of hazardous substances must be kept to a minimum.
- Hazardous material containers must be clearly labelled with their content and any hazard symbols. They
 must also be registered. They should be resealed immediately after use.
- For containers above 1 liter, the containers must also be completely labelled with the H and P sets.
- Containers intended for food (beverage bottles, jam jars etc.) must not be used for hazardous substances.
- Only containers resistant to the substance may be used.
- At the workplace (for example, at lab tables), only the maximum daily requirement amount can be kept.
- (Very) toxic substances should be stored under lock and key so that only qualified persons have access.
 - Never carry (glass) bottles by the neck or lid. When transporting outside the laboratory, these must always be transported in plastic boxes that can catch the hazardous substance in case of leaks.
- Food cannot be stored together with hazardous substances (e.g. in the fridge).
- In the case of open handling of gaseous, dusty or hazardous substances that have a high vapor pressure, always work in the fume hood.

10.7.2 Hazardous material operating instructions

For the handling of "more dangerous" substances, the above-mentioned persons responsible will prepare hazardous substance operating instructions that list the most important protective measures and rules of conduct. These operating instructions must be observed!

10.7.3 Handling gas cylinders

- The use of gas cylinders in the laboratory may only be carried out for a short time, insofar as these are not installed in suitable safety cabinets.
 - For permanent use (as well as when using toxic gases), fixed gas lines must be laid.
- The number of gas cylinders in a room should be kept as low as possible. Unnecessary bottles must be returned to the outdoor gas storage facility.
- Gas cylinders must always be secured against falling over with a gas cylinder holder, a steel bracket or a chain.
- Gas cylinders must be protected from heat.



- Rooms in which gas cylinders are installed outside safety cabinets are to be marked on the door with a
 warning sign "Gas cylinder warning", which also indicates the type and quantity of substances.
- Gas cylinders containing toxic, corrosive or highly flammable gases should be chosen as small as
 possible.
- Rooms containing gas cylinders with flammable gases outside safety cabinets must be well ventilated and equipped with a gas detector.
- Gas cylinders for toxic gases may only be installed or connected in extracted cabinets or fume hoods.
- Gas cylinders may only be moved using special transport trolleys and only with the valve cap screwed on. Carrying bottles is strictly prohibited.
- Only gas fittings and hoses that are permissible for the respective type of gas and the pressure occurring
 may be used to remove gas from compressed gas cylinders. Particular care must be taken to ensure
 that oxygen does not come into contact with fats or oils, and acetylene does not come into contact with
 heavy metals such as copper or lead.
- Compressed gas cylinders which extraction valves cannot be opened by hand must be marked and taken out of service.
- Gas cylinder valves should only be opened (carefully) shortly before the start of the test and closed again immediately after the end of the test.
- Keep valves free of grease and oil, especially with oxidizing gases.
- Gas hoses must always be visually inspected before use. Porous, severely kinked or damaged hoses should not be used.
- When connecting gas hoses, always ensure that they are tight.
- When transporting gas areas in elevators, make sure that no persons are traveling in the elevator. For this purpose, barriers and warnings are to be used.

10.7.4 Liquid gases

- Liquefied gases may only be transported in the vessels provided for this purpose (steel insulated tanks, drinking cans).
- They must not be used or stored in small, unventilated rooms.
- When transferring cryogenic gases, cold protective gloves must be worn.

10.7.5 Binder for spilled liquids

Spilled liquids / oils should be sprinkled with sand orbinder (location: location: mechanical workshop) and then taken up with a hand brush / dustpan.

10.8 Dangerous activities

Activities with an increased risk of fire or injury (e.g., working with circular saws, corrosive hazardous substances, dangerous electrical voltages, lasers of classes 3B and 4) may only be carried out if at least one other person is present, even if the specially required protective measures are taken. This person must be able to provide first aid or get help in case of danger.

10.9 Unsupervised experimental setups

Unsupervised experiments are only permitted, if it is guaranteed that

- other people cannot intervene in the experiment or be endangered by it,
- dangerous conditions cannot occur, even in the event of power failure, cooling water etc...
- there is no increased risk of fire due to overheating, for example.

11 Waste

- Expendable waste must be placed in the designated waste containers.
- Electronic waste, toner and used batteries should be taken to the collecting boxes.
- The amount of hazardous waste can be reduced by using only small quantities of substances in reactions. Preference should be given to further use and reprocessing, e.g. of solvents, before their disposal. Reactive residues, e.g. Alkali metals, peroxides, hydrides, Raney nickel, are to be properly converted to less hazardous substances.
- Solvent mixtures should be neutral and peroxide-free. For filling, the solvent tons must be put in the fume cupboard.

Aktualisiert: 03.04.2025 Druck: 03.04.2025 Ersteller/Bearbeiter: Laboratory of Nano-Optics Seite 9 von 9 2025 ENGL Laborordnung chemielab



•	Residues that are not reusable and classified as special waste due to their properties must be packed, labelled, declared and reported to the central hazardous waste disposal (Mr. Sakalli, tel2222) in accordance with the separately issued guideline for the collection and disposal of hazardous waste at the university and be handed over for disposal. The same applies to waste chemicals and compressed gas bottles to be disposed of. The applicable transport regulations must be observed.

Siegen, date 03.04.2025

Prof Mario Agio Supervisor of Laboratory of Nano-Optics